



INSTALLATION

1 - LOOSEN THE M3 SET SCREW [A] LOCATED AT THE BOTTOM OF STEPLIGHT [B] AS SHOWN USING THE SUPPLIED ALLEN KEY [C] TO FACILITATE INSTALLATION.

2 - INSTALLATION ON 2" X 3" SWITCH BOX
INSTALL THE 2" X 3" SWITCH BOX (SUPPLIED BY OTHERS) VERTICALLY. INSTALL THE GASKET [D] AND THE MOUNTING PLATE [E] OVER THE SWITCH BOX USING 2-WAY #6-32 MOUNTING SCREWS [F]. MAKE ALL WIRING CONNECTION.

3 - FASTEN GENTLY THE 2-WAY #6-32 MOUNTING SCREWS [F] TO THE SWITCH BOX. AVOID OVER TIGHTENING THE SCREWS TO PREVENT GAP BETWEEN GASKET AND THE 2" X 3" SWITCH BOX.

FOR WET LOCATION INSTALLATION, IT IS SUGGESTED TO APPLY SILICONE CAULKING AROUND GASKET [D]

4 - POSITION STEPLIGHT [B] ON THE MOUNTING PLATE [E] & GASKET [D] USING THE FLANGE/TAB LOCATED INSIDE THE STRUCTURE OF STEPLIGHT [B] AS SHOWN.

5 - SLIDE STEPLIGHT [B] OVER THE MOUNTING PLATE [E]. GENTLY PRESS THE STRUCTURE AGAINST WALL SURFACE.

6 - HOLD THE STEPLIGHT [B] INTO PLACE WHILE TIGHTEN THE STRUCTURE WITH THE BOTTOM M3 SET SCREW [A]. USE THE PROVIDED ALLEN KEY TO EXECUTE THIS OPERATION.

MAINTENANCE

7 - FOR LED REPLACEMENT BULB: PLEASE CONTACT YOUR EUREKA AGENT.

INSTALLATION

1 - DÉVISSER LA VIS DE PRESSION À SIX PANS CREUX M3 [A] LOCALISÉS SUR L'ENCASTRÉ MURAL [B] À L'AIDE DE LA CLEF SIX PANS (ALLEN) [C] FOURNIE POUR FACILITER L'INSTALLATION.

2 - INSTALLATION DE LA BOÎTE DE CONNEXION 2" X 3"
INSTALLER LA BOÎTE DE CONNEXION 2" X 3" (NON-INCLUSE) VERTICALEMENT. POSER LE JOINT D'ÉTANCHÉITÉ [D] ET LA PLAQUE DE MONTAGE [E] AU MUR À L'AIDE DES (2) VIS DE MONTAGE #6-32 FOURNIES [F]. FAIRE LA CONNEXION DES FILS.

3 - VISSER SANS FORCER LES (2) VIS DE MONTAGE #6-32 [F] À LA BOÎTE DE CONNEXION. PRENDRE GARDE DE NE PAS TROP SERRER LES VIS AFIN D'ÉVITER TOUT ÉPACEMENT CRÉÉ ENTRE LE JOINT D'ÉTANCHÉITÉ ET LA BOÎTE DE CONNEXION 2" X 3".

POUR L'INSTALLATION AU EMPLACEMENT HUMIDE, C'EST SUGGÉRÉ DE METTRE DE LA SILICONE AUTOUR DU JOINT D'ÉTANCHÉITÉ [D]

4 - POSITIONNER L'ENCASTRÉ MURAL [B] EN UTILISANT LA LANGUETTE PLIÉE DE LA STRUCTURE POUR L'ACCROCHER SUR LA PLAQUE DE MONTAGE [E].

5 - DÉPOSER L'ENCASTRÉ MURAL [B] SUR LA PLAQUE DE MONTAGE [E] EN L'APPUYANT FERMEMENT CONTRE LA SURFACE DU MUR.

6 - TENIR L'ENCASTRÉ MURAL [B] EN PLACE ET SERRER L'ENSEMBLE DE LA STRUCTURE À L'AIDE DE LA VIS DE PRESSION À SIX PANS CREUX M3 [A]. UTILISER LA CLEF SIX PANS (ALLEN) [C] FOURNIE POUR EXÉCUTER CETTE OPÉRATION.

MAINTENANCE

7 - POUR LES INFORMATIONS RELIÉES AU REMPLACEMENT DES DEL: VEUILLEZ CONTACTER VOTRE AGENT EUREKA.