



INSTALLATION

REMOVE 2-WAY SCREW [A] (M4 X 0.7 X 18mm) TO RELEASE THE MOUNTING RECTANGULAR CANOPY [D].

1 - INSTALLATION ON 4" JUNCTION BOX

INSTALL THE UNIVERSAL CROSSBAR [B], AND MAKE ALL WIRING CONNECTIONS.

1A-DIRECT INSTALLATION (BX, FLEXIBLE ARMoured CABLE)

ATTACH THE FLEXIBLE ARMoured CABLE FITTING AND CABLE (SUPPLIED BY OTHERS) TO THE MOUNTING CANOPY [D]. MOUNT IT TO THE WALL WITH 2-WAY #8 MOUNTING SCREW [F] & ANCHOR [G] AND MAKE ALL WIRING CONNECTIONS. GO DIRECTLY TO STEP 3.

2 - INSTALL SQUARE CANOPY PLATE [C] AND THE MOUNTING RECTANGULAR CANOPY [D] TO THE JUNCTION BOX USING 2-WAY MOUNTING SUPPLIED SCREWS [E]. SECURE IT INTO PLACE WITH 2-WAY #8 MOUNTING SCREW [F] & ANCHOR [G].

3 - ASSEMBLE THE BALLAST HOUSING [H] TO THE MOUNTING RECTANGULAR CANOPY [D] WITH 2-WAY SCREW [A]. USE [A*] FOR LED ONLY.

4 - REMOVE 2-WAY SCREW [I] (M4 X 0.7 X 6mm) TO RELEASE THE END CAP. SLIDE OTHER END OF THE GLASS SHADE [K] AGAINST THE OTHER END CAP AND HOLD GLASS SHADE IN POSITION.

5 - REINSTALL THE END CAP [J] WITH 2-WAY SCREW [I].

6 - SECURE THE GLASS SHADE [K] WITH 2-WAY M4 SET SCREW [L] BY USING PROVIDED ALLEN KEY [M].

INSTALLATION

AVANT DE COMMENCER D, ÉVISSER LES 2 VIS [A] (M4 X 0.7 X 18mm) POUR LIBÉRER LA STRUCTURE DE CANAPÉ RECTANGULAIRE [D].

1 - INSTALLATION DE LA BOÎTE ÉLECTRIQUE 4"

INSTALLER LA PLAQUE UNIVERSELLE [B] ET FAIRE LA CONNEXION DES FILS.

1A - INSTALLATION DIRECTE (BX, CABLE FLEXIBLE ARMÉ)

INSTALLER LE CONNECTEUR POUR CABLE ARMÉ ET LE CABLE (NON-INCLUSE) SUR LA STRUCTURE DE CANAPÉ [D]. VISSER L'ENSEMBLE DE STRUCTURE DIRECTEMENT AU MUR GRÂCE AUX VIS DE MONTAGE #8 [F] & AUX CHEVILLES [G] ET FAIRE LA CONNEXION DES FILS. ALLER DIRECTEMENT À L'ÉTAPE 3.

2 - FIXER LA PLAQUE CARRÉE [C] ET LA STRUCTURE DE CANAPÉ RECTANGULAIRE [D] SUR LA BOÎTE ÉLECTRIQUE À L'AIDE DES (2) VIS DE MONTAGE FOURNIES [E]. SÉCURISER L'ENSEMBLE DE STRUCTURE DIRECTEMENT AU MUR GRÂCE AUX VIS DE MONTAGE #8 [F] & AUX CHEVILLES [G].

3 - MONTER LE KIT ÉLECTRIQUE SUR LA STRUCTURE DE CANAPÉ RECTANGULAIRE [D] À L'AIDE DES 2 VIS [A]. LES RONDELLES [A*]- LED SEULEMENT.

4 - DÉVISSER LES 2 VIS [I] (M4 X 0.7 X 6mm) POUR LIBÉRER L'EMBOUT [J]. GLISSER EN PLACE L'ABAT-JOUR EN VERRE [K] EN BIEN L'APPUYANT CONTRE L'AUTRE EMBOUT.

5 - REMETTRE EN PLACE LE COUVERCLE [J] A L'AIDE DES (2) VIS [I].

6 - SÉCURISER LE DIFFUSEUR EN VERRE [K] À L'AIDE DES (2) VIS M4 [L] EN UTILISANT LA CLÉ ALLEN [M].