



INSTALLATION

- 1- OPEN THE BOX AND TAKE OUT ALL THE PANELS AND BLADES
- 2- ASSEMBLE THE MAIN PANELS TOGETHER BY PUSHING THE TOP PART ONTO THE BOTTOM PART
- 3- THE MAIN PANELS WILL MAKE A 90° ANGLE FOR EACH SIDE
- 4- INSERTS THE CLIPS OF THE BLADE INSIDE THE HOLES OF THE MAIN PANELS, REPEAT THE PROCESS FOR THE 3 REMAINING BLADES
- 5- FASTEN GRIPPERS WITH APPROPRIATE ANCHORS & SCREWS (NOT INCLUDED).
- 6- INSTALLATION SHEET IS VALID FOR ALL UNLIT ELKE, JOLI & MARRO.

INSTALLATION

- 1- OUVREZ LA BOÎTE ET RETIRER TOUTES LES PIÈCES DE CELLE-CI.
- 2- ASSEMBLEZ LES PANNEAUX PRINCIPAUX ENSEMBLE EN INSÉRANT LE PANNEAU DU DESSUS DANS CELUI DU DESSOUS.
- 3- LES PANNEAUX PRINCIPAUX FORMERONT DES ANGLES DE 90°
- 4- INSÉREZ LES CLIPS DES AILETTES À L'INTÉRIEUR DES TROUS , RÉPÉTEZ LE PROCESSUS POUR LES 3 AILETTES RESTANTES.
- 5- FIXER LE SERRE-CÂBLE AU PLAFOND À L'AIDE D'ANCRAGES APPROPRIÉS ET VIS (NON INCLUS).
- 6- LA FEUILLE D'INSTALLATION EST VALIDE POUR LES MODÈLES UNLIT ELKE JOLI ET MARRO