



INSTALLATION

- 1- DRILL MOUNTING HOLES AND SCREW IN ANCHORS.
SCREW THREADED RINGS FROM CEILING GRIPPER [A] INTO ANCHORS.
- 2- LIFT FIXTURE AND TURN TOP SECTION TO SCREW THREADED STEM INTO ANCHORED COMPONENT.
- 3- HOLD BOTTOM OF FIXTURE WHILE INSERTING THE 15 FELT SHADE PANELS BY SLIDING THEM INTO THE TEETH OF THE TWO CORRESPONDING TOOTHED PLATES.

INSTALLATION

- 1- PERCER LES TROUS DE MONTAGE ET VISSER LES ANCRAGES.
VISSER LES ANNEAUX FILETÉE DU SERRE-CÂBLE [A] DANS ANCRAGES.
- 2- LEVER FIXTURE ET TOURNER SECTION DU HAUT POUR VISSER TIGE FILETÉE DANS PIÈCE ANCRÉES.
- 3- TENIR BAS DE LA FIXTURE ET INSÉRER LES 15 PANNEAUX DE FEUTRE DE L'ABAT-JOUR EN LES GLISSANT DANS LES DENTS DES DEUX PLAQUES DENTÉES CORRESPONDANTES.